




Please order by part number, not key number.

SPINNING REEL TD700i/1000i



No. 2-9 F29-6706 Spool assembly

Key NO.	Parts No.	Parts Name
1	F20-4405	Drag knob
2	171-7701	Drag washer retainer
3	E13-6101	Key washer
4	E13-6001	Drag washer
5	E13-6201	Eared washer
6	E29-7808	Spool assembly
7	E13-2101	Click pawl
8	B61-8801	Click spring
9	320-5901	Click retainer
10	E39-4001	Spool washer
11	E36-5301	Click gear
12	F15-8401	Main shaft
13	341-9203	Rotor nut
14	F22-8102	Rotor
15	F03-0801	Bail trip lever
16	F15-3104	Bail trip cover
17	E36-4201	Bail trip cover screw
18	B67-9305	Line roller screw
19	F15-2405	Bail arm
20	F15-2501	Bail arm screw
21	F06-6301	Line roller collar
22	F05-5601	Ball bearing A
23	F05-8901	Line roller
24	F17-4701	Bail assembly
25	F15-2501	Bail trip cam screw
26	320-5901	Bail trip cam screw retainer
27	320-5901	Bail arm screw retainer
28	E36-8201	Bail spring shaft
29	E37-2401	Bail spring
30	F15-2604	Bail spring cover
31	E36-4201	Bail spring cover screw
32	F19-7201	Oiled washer
33	F15-3301	Roller clutch
34	F21-2501	Roller clutch retainer
35	F15-5101	Spacing sleeve
36	F21-2201	Bearing retainer screw
37	637-5701	Ball bearing B
38	F15-1002	Pinion gear
39	F26-4701	Body assembly
40	F15-1201	Anti-reverse ratchet

Key NO.	Parts No.	Parts Name
41	F15-1102	Bearing retainer
44	L00-1801	Anti-reverse pawl screw
45	F15-1501	Anti-reverse pawl
46	F15-8301	Anti-reverse pawl collar
47	F15-1601	Anti-reverse pawl spring
48	F17-4301	Worm shaft
49	F12-2601	Oscillating slider
50	E12-2403	Oscillating pawl
51	E12-4601	Oscillating pawl bush
52	375-0800	Oscillating pawl washer
53	E11-6801	Oscillating slider cover
54	E15-0203	Oscillating slider cover screw
55	375-4101	Worm shaft washer
56	F05-6901	Worm shaft collar
57	F08-7201	Shield plate
58	F15-1701	Pinion collar
59	F15-0701	Anti-reverse cam spring
60	F15-0803	Anti-reverse lever
61	F15-3703	Water shield
62	F15-3803	Rear cover
63	E24-8102	Rear cover screw
64	E42-0102	Drive gear
65	375-8500	Drive gear washer
66	637-5701	Ball bearing B
67	F15-2203	Side cover
68	E13-0502	Side cover screw A
69	E13-0501	Side cover screw B
70	F16-9301	Handle collar
71	F30-3701	Handle screw
72	F15-4402	Handle screw cap
73	F26-4801	Handle assembly
74	F26-3101	Spacer
75	375-8507	Rotor washer
76	F26-8501	Ball bearing collar

TD10001 SPECIAL PARTS

2-9	F15-8505	Spool assembly
6	F15-8605	Spool assembly
14	F21-6002	Rotor
24	F15-4501	Bail assembly