


SPINNING REEL

REGAL-Z3505T



Key No.	Parts No.	Parts Name
2-9	F48-3601	Spool assembly
1	F42-1905	Drag knob
2	F37-3301	Drag washer retainer
3	F09-4901	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F48-3701	Spool assembly
7	B07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	F09-4701	Spoolwasher
11	E46-2701	Click gear
12	F48-0002	Main shaft
13	F09-1301	Oscillating slider
14	352-1502	Oscillating slider screw
15	340-6602	Rotor nut
16	F42-1805	Rotor assembly
17	B67-9308	Line roller screw
18	F45-2701	Bail arm
19	E49-3501	Bail arm screw
20	320-5901	Bail arm Screw retainer
21	F44-6302	Line roller collar
22	F44-6201	Line roller washer
23	F05-5601	Ball bearing A
24	F45-4902	Line roller
25	F48-4801	Bail assembly
26	F40-1001	Bail holder washer
27	B84-2102	Bail trip cam screw
28	E46-2101	Bail trip lever
29	F18-0005	Trigger lever

Key No.	Parts No.	Parts Name
30	E36-9901	Trigger spring
31	E41-7801	Trigger screw
32	F12-8901	Bail spring
33	F31-4505	Bail spring cover
34	E24-8101	Bail spring cover screw
35	F31-4605	Bail trip cover
36	E46-2001	Anti-reverse pawl spring
37	F24-8901	Anti-reverse ratchet
38	L03-6502	Ball bearing B
39	E52-0101	Pinion gear
40	F48-3403	Body assembly
41	E00-7101	Anti-reverse pawl screw
42	E46-1302	Anti-reverse pawl
43	E46-1201	Anti-reverse pawl spring
44	E03-7801	Bearing retainer screw
45	E32-7801	Anti-reverse cam spring
46	F08-5125	Anti-reversa lever
47	F13-1601	Oscillating gear collar
48	F24-6601	Oscillating gear
49	631-6901	Ball bearing C
50	E52-0201	Drive gear
51	373-7805	Drive gear washer
52	631-6901	Ball bearing C
53	F48-3503	Side cover
54	B83-5002	Side ewer screw
55	E15-8602	Side cover screw
56	F50-3801	Handle assembly
57	F43-3501	Handle collar
58	B92-5010	Handle lock screw