


SPINNING REEL **TOURNAMENT-Z4000i**



Key

Key No.	Parts No.	Parts Name
2-8	F47-7901	Spool assembly
1	F47-8101	Drag knob
2	F06-2601	Drag washer retainer
3	F01-6001	Click plate washer
4	E12-2803	Drag knob click plate
5	B36-0204	Drag washer
6	E15-0101	Eared washer
7	B65-2302	Key washer
8	F47-8001	Spool assembly
9	F13-7501	Spool washer
10	F47-5901	Main shaft assembly
11	B74-7702	Spool click leaf spring
12	B10-5702	Rotor nut
13	F18-9601	Rotor nut holding plate
14	E13-4501	Rotor nut holding plate screw
15	F47-7401	Rotor
16	F14-2004	Line roller screw
17	F45-4301	Bail arm
18	F34-5901	Bail arm screw
19	320-5901	Bail arm screw retainer
20	F44-6303	Line roller collar
21	F44-6202	Line roller washer
22	F45-4902	Line roller
23	F05-5601	Ball bearing A
24	F47-7501	Bail assembly
25	E12-4701	Bail spring shaft
26	E31-3901	Bail spring washer
27	E43-5401	Bail spring
28	F35-6903	Bail spring cover
29	F01-3703	Bail spring cover screw
30	F35-7201	Bail trip plate
31	F49-9201	Bail trip lever
32	F35-7303	Bail trip cover
33	F19-7302	Oiled washer
34	F18-2901	Roller clutch
35	351-4701	Roller clutch screw
36	F24-6001	Spacing sleeve
37	F23-9102	Anti-reverse ratchet
38	F23-8301	Bearing retainer
39	F22-6801	Anti-reverse pawl collar A
40	F23-8801	Anti-reverse pawl plate
41	E45-4001	Anti-reverse pawl screw
42	F23-8901	Anti-reverse pawl

Key

Key No.	Parts No.	Parts Name
43	F22-7101	Anti-reverse pawl spring
44	351-8501	Bearing retainer screw
45	F24-0001	Ball bearing B
46	371-2822	Spacer A
47	371-2821	Spacer B
48	F36-6901	Pinion gear
49	B88-0001	Pinion collar
50	F47-7301	Body assembly
51	E26-8701	Anti-reverse cam spring
52	E45-0403	Anti-reverse lever
53	320-5901	Worm shaft gear retainer
54	E44-8202	Worm shaft gear
55	B45-1501	Worm shaft bush
56	E33-2501	Ball bearing C
57	F28-3401	Worm shaft
58	F28-2602	Worm shield cover
59	E44-6702	Oscillating slider
60	F02-1202	Oscillating pawl
61	E19-1301	Oscillating pawl bush
62	375-0801	Oscillating pawl washer
63	E12-5901	Oscillating slider cover
64	351-8903	Oscillating slider cover screw
65	375-4101	Worm shaft washer
66	F28-2201	Ball bearing D
67	F28-2301	Worm shaft retainer
68	F28-2403	Worm shaft collar
69	E45-0702	Water shield
70	E45-0806	Rear cover
71	F01-6302	Rear cover screw
72	B86-1701	Ball bearing E
73	E44-7004	Drive gear
74	373-7808	Drive gear washer
75	B62-8601	Ball bearing F
76	F08-5004	Side cover
77	351-8505	Side cover screw
78	F43-3502	Handle collar
79	F04-5002	Handle screw
80	F24-6202	Handle screw cap
81	F50-2801	Handle assembly
82	F23-8701	Anti-reverse pawl collar B