


# SPINNING REEL TEAM DAIWA-S3500iT/4000iT



**Key No.**

Key No.	Parts No.	Parts Name
2-6	F52-5501	Spool assembly
1	F20-4607	Drag knob
2	170-4101	Drag washer retainer
3	E27-7801	Key washer
4	B36-0204	Drag washer
5	372-3832	Eared washer
6	F52-5601	Spool assembly
7	E39-7901	Spool washer
8	E12-2302	Click [eat spring holder
9	B74-7702	Spool click leaf spring
10	375-4202	Main shaft washer
11	E41-3101	Click gear
12	F18-5801	Main shaft
13	F18-9601	Rotor nut holding plate
14	B93-3001	Rotor nut holding plate screw
15	B10-5701	Rotor nut
16	F49-9902	Rotor assembly
17	F08-0702	Bail trip plate
18	F48-2301	Bail trip lever
19	F50-0502	Bail trip cover
20	F38-5103	Rail trip cover screw
21	B67-9309	Line roller screw
22	F48-1902	Bail arm
23	F48-7501	Bail arm screw
24	F44-6303	Line roller collar
25	F44-6202	Line roller washer
26	F05-5601	Ball bearing A
27	F45-4902	Line roller
28	F52-5201	Bail assembly
29	320-5901	Bail trip cam screw retainer
30	F24-6801	Bail spring shaft
31	F36-2501	Bail spring
32	F50-0202	Bail spring cover
33	E24-8103	Bail spring cover screw
34	F19-7302	Oiled washer
35	F18-2901	Roller clutch
36	F18-3001	Roller clutch retainer
37	E15-7502	Roller clutch retainer screw
38	F18-1301	Spacing sleeve
39	F18-1401	Anti-reverse ratchet
40	F18-1201	Bearing retainer
41	883-4402	Bearing retainer screw
42	635-4801	Ball bearing B
43	F26-5101	Pinion gear
44	L00-1801	Anti-reverse pawl screw

**Key No.**

Key No.	Parts No.	Parts Name
45	F18-1801	Anti-reverse pawl
46	F18-1701	Anti-reverse pawl collar
47	F37-4501	Anti-reverse pawl spring
48	F52-5101	Body assembly
49	E32-7801	Anti-reverse cam spring
50	F18-1002	Anti-reverse lever
51	E42-0501	Worm shaft gear
52	F30-7802	Worm shaft
53	E37-6301	Oscillating slider
54	E19-1203	Oscillating pawl
55	E19-1301	Oscillating pawl bush
56	375-0801	Oscillating pawl washer
57	E37-6901	Oscillating slider cover
58	E40-1501	Oscillating slider cover screw
59	653-6100	Worm shaft washer
60	F05-6901	Worm shaft collar
61	E48-2801	Shield plate
62	E48-2701	Pinion collar
63	F18-3403	Water shield
64	F18-3508	Rear cover
65	E36-4203	Rear cover screw
66	B86-1701	Ball bearing C
67	E41-8603	Drive gear
68	373-7802	Drive gear washer
69	E15-4001	Ball bearing D
70	F18-2307	Side cover
71	E15-8603	Side cover screw A
72	E15-7502	Side cover screw B
73	F43-3502	Handle collar
74	363-8511	Handle screw
75	F52-6501	Handle cap
76	F52-5301	Handle assembly

**S4000iT SPECIAL PARTS**

**Key No.**

Key No.	Parts No.	Parts Name
2-6	F52-6701	Spool assembly
6	F52-6801	Spool assembly
16	F50-0602	Rotor assembly
28	F52-6601	Bail assembly