


SEALINE REEL

STS-X300CI/X400CI/X500CI/X600CI



STS-X300CI


KEY NO.	PART NO.	PART NAME
1	F55-5802	L/S PLT
2	320-8002	SPOOL GEAR RET
3	E36-0301	SPOOL GEAR
4	F54-1902	IC MODULE
5	352-9503	IC MODULE SCREW
6	F55-6301	LEFT SET PLT
7	351-7705	CHANGE GEAR SCREW
8	F57-1902	CHANGE GEAR SCREW WASHER
9	F54-0701	CHANGE GEAR SCREW COLLAR
10	F55-6401	CHANGE GEAR
11	E24-7701	LEFT SET PLT SCREW
12	B18-1601	SPOOL BALL BEARING
13, 15	375-5803	SPOOL BEARING WASHER
14	F55-7801	SPOOL
16	F56-5601	FRAME
17	F55-6601	INPUT ROLLER
18, 31	320-5901	WORM SHAFT GEAR RET
19, 30	373-1602	WORM SHAFT GEAR WASHER
20	F55-3401	WORM SHAFT GEAR
21	F55-3301	WORM SHAFT
22	E14-4801	WORM SHAFT BUSH (L)
23	F55-3501	WORM SHIELD
24	F55-3601	LEVEL WIND
25	122-0601	LINE GUIDE PAWL
26	375-4101	LINE GUIDE PAWL WASHER
27	E35-4101	PAWL CAP
28	F46-7201	WORM SHAFT BUSH (R)
29	F55-6901	WORM SHAFT HOLDER WASHER
32	B86-4101	LEVEL WIND POST RET
33	F55-3901	LEVEL WIND POST
34	F55-4401	SLIDE PLT SCREW
35	F55-4001	SLIDE PLT
36	F55-4501	SLIDE PLT COLLAR
37	375-3003	SLIDE PLT WASHER
38	F61-8001	KICK LEVER
39	F56-1801	KICK LEVER SPRING

STS-X300CI

KEY NO.	PART NO.	PART NAME
40	F57-1901	KICK LEVER WASHER
41	B00-8601	KICK LEVER SCREW
42	E25-9101	CLUTCH PLT
43	E03-7704	CLUTCH PLT WASHER
44	E33-5301	CLUTCH LEVER SPRING
45	F55-4701	PINION GEAR
46	F55-9101	R/S PLT
47	E28-6003	LINE HOLDER
48	F55-2801	CLUTCH CAM
49	F50-8801	CLUTCH CAM SPRING
50	F55-2901	CLUTCH LEVER
51	160-8001	CLUTCH LEVER WASHER
52	E00-7601	CLUTCH LEVER SCREW
53	F55-6501	R/S PLT SCREW A
54	F58-2701	R/S PLT SCREW B
55	B00-8601	R/S PLT SCREW C
56	375-7405	MECHANICAL BRAKE WASHER A
57	B17-5501	MECHANICAL BRAKE WASHER B
58	E03-3201	MECHANICAL BRAKE LEAF SPG
59	E48-9608	MECHANICAL BRAKE KNOB
60	374-9102	GEAR SHAFT WASHER
61	B73-8001	GEAR SHAFT BUSH
62	F55-4801	GEAR SHAFT
63	F55-4901	GEAR SHAFT RET
64	E31-6701	GEAR SHAFT RET SCREW
65	F55-5001	A/R RATCHET
66	374-6604	A/R RATCHET WASHER
67	F55-5301	DRIVE GEAR
68	F11-4802	DRAG WASHER
69	B36-0302	DRAG DISC WASHER
70	372-3833	EARED WASHER
71	F55-5401	HANDLE METAL COLLAR
72	E24-8101	HANDLE METAL PLT SCREW
73	F58-0801	HANDLE METAL PLT
74	F55-2501	HANDLE METAL
75	F36-6802	HANDLE BEARING WASHER A

Please order by part number, not key number.

STS-X300CI/X400CI/X500CI/X600CI SEALINE REEL



STS-X300CI

KEY

NO.	PART NO.	PART NAME
76	F05-5501	HANDLE BEARING
77	F36-6801	HANDLE BEARING WASHER B
78	E25-3501	DRAG SPRING WASHER
80	F17-0501	DRAG HOLDER
81	B74-7702	DRAG HOLDER LEAF SPRING
82	F55-0408	STAR DRAG
83	E25-3901	HANDLE WASHER
84	F55-7601	HANDLE
85	B86-2101	HANDLE NUT
86	F47-1201	HANDLE NUT PLT
87	F61-8701	A/R PAWL SPRING
88	F00-8001	A/R PAWL COLLAR
89	F06-9801	A/R PAWL
90	E25-2301	A/R PAWL PIN

STS-X400CI SPECIAL PARTS

KEY

NO.	PART NO.	PART NAME
1	F55-5804	L/S PLT
4	F54-1905	IC MODULE
14	F55-9301	SPOOL
16	F56-5701	FRAME
17	F55-8901	INPUT ROLLER
21	F55-8301	WORM SHAFT
23	F56-1701	WORM SHIELD
33	F55-8401	LEVEL WIND POST
53	F58-3001	R/S PLT SCREW A
54	F55-6501	R/S PLT SCREW B

STS-X500CI SPECIAL PARTS

KEY

NO.	PART NO.	PART NAME
1	F56-2702	L/S PLT
4	F54-1908	IC MODULE
6	F56-3501	LEFT SET PLT
7	352-0407	CHANGE GEAR SCREW

STS-X500CI SPECIAL PARTS

KEY

NO.	PART NO.	PART NAME
14	F56-5201	SPOOL
16	F56-2202	FRAME
17	F56-3301	INPUT ROLLER
21	F56-2401	WORM SHAFT
23	F56-2501	WORM SHIELD
33	F56-2601	LEVEL WIND POST
45	F55-4701	PINION GEAR
46	F56-5101	R/S PLT
53	F56-3201	R/S PLT SCREW A
54	F58-6301	R/S PLT SCREW B
67	F56-3801	DRIVE GEAR

STS-X600CI SPECIAL PARTS

KEY

NO.	PART NO.	PART NAME
1	F56-2704	L/S PLT
4	F54-1911	IC MODULE
6	F56-3501	LEFT SET PLT
7	352-0407	CHANGE GEAR SCREW
14	F56-5401	SPOOL
16	F56-3902	FRAME
17	F56-4801	INPUT ROLLER
21	F56-4101	WORM SHAFT
24	F56-4201	LEVEL WIND
33	F56-4301	LEVEL WIND POST
45	F56-3701	PINION GEAR
46	F56-5101	R/S PLT
53	F56-4701	R/S PLT SCREW A
54	F58-6401	R/S PLT SCREW B
67	F56-3801	DRIVE GEAR