


# PROCASTER-X153iV



**Key No. Parts No.**

**Parts Name**

1	F40-3615	BRAKE ADJ KNOB
2	F03-2401	BRAKE CLICK SPRING
3	F64-7701	L/S PLT
4	B84-2102	BRAKE ADJ KNOB SCREW
5	374-9103	SPACER A
6	F40-3701	BUSHING A
7	F41-2301	BEARING RET
8	E23-9501	MAGNET HOLDER
9-11	F64-8002	SPOOL
12	F64-6901	FRAME
13	F40-2003	CLUTCH LEVER
14	F42-8801	CLUTCH TRIP PLT
15	F44-0201	CLUTCH TRIP PLT RET
16	F63-9901	CLUTCH TRIP PLT SPRING
17	F40-2801	PAWL CAP
18	F51-6501	LINE GUIDE PAWL
19	F51-0301	WORM SHAFT
20	F67-5101	WORM SHAFT GEAR
21	B86-1701	BALL BEARING A
22	F73-1201	CLUTCH CAM SPRING
23	F64-7001	CLUTCH CAM
24	E24-9103	A/R LEVER
25	F58-3401	PINION GEAR
26	E23-7701	YOKE
27	E16-7101	YOKE SPRING
28	E21-9701	BEARING RET B
29	F64-8301	BUSHING B
30	F40-7823	R/S PLT
31	F65-0401	PINION SHAFT
32	B17-5401	SPOOL ADJ CAP METAL
33	B17-5503	SPACER C

**Key No. Parts No.**

**Parts Name**

34	171-5201	O RING A
35	F40-3003	CAST CONTROL CAP
36	E33-0402	SET PLT SCREW
37	B85-3101	O RING B
38	B91-1727	R/S PLT SCREW
39	F64-7201	DRIVE SHAFT WASHER
40	B55-0301	BUSHING C
41	F64-7301	DRIVE SHAFT RET
42	F21-2201	DRIVE SHAFT RET SCREW
43	F64-7101	DRIVE SHAFT
44	E32-7701	A/R RATCHET
45	375-7103	DRIVE SHAFT WASHER B
46	F40-2501	DRIVE GEAR
47	F60-2401	DRAG WASHER A
48	B36-0303	KEY WASHER
49	E42-5401	DRAG WASHER B
50	F40-7901	GEAR SHAFT COLLAR
51	F40-8001	ROLLER CLUTCH
52	F05-5501	BALL BEARING B
53	B55-3801	DRAG WASHER C
54	373-7810	DRAG WASHER D
55	150-8901	DRAG SPRING WASHER
56	B97-4901	SPACING SLEEVE
57	F40-3203	STAR DRAG
58	B43-3601	DRAG NUT
59	150-9001	FRICTION WASHER
60	F64-7601	HANDLE
61	B43-3601	HANDLE NUT
62	F40-8402	HANDLE NUT RET
63	374-9105	SPACER B