


BAITCASTING REEL MILLIONAIRE-CV-X103A



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G00-2202	L/S OUTER RING	46	B17-5401	SPOOL ADJ CAP METAL
2	G00-1301	BEARING RET A	47	B17-5503	SPACER D
3	G05-0801	L/S PLT	48	F57-4403	CAST CONTROL CAP
4	G00-2301	O RING A	49	B86-4101	STABILIZER BAR RET
5	F79-8001	BRAKE CLICK SPRING	50	F97-3201	STABILIZER BAR
6	G00-2401	BRAKE ADJ KNOB	52	320-5901	WORM SHAFT RET
7	375-7404	SPACER A	53	373-1303	WORM SHAFT WASHER
8	375-7411	SPACER B	54	F79-5801	WORM SHAFT HOLDER A
9	F57-4303	SPACER C	55	F79-5101	WORM SHIELD
10	E08-8003	BALL BEARING A	56	G05-0402	LINE GUIDE
11	E21-9701	BEARING RET B	57	F96-6001	LINE GUIDE PAWL
12-20	G05-1601	SPOOL	58	375-4101	LINE GUIDE WASHER
21	G05-0201	FRAME	59	F40-2803	PAWL CAP
22	G00-0302	CLUTCH LEVER PLT A	60	F79-5501	WORM SHAFT HOLDER B
23	G00-0404	CLUTCH LEVER	61	F84-9102	WORM SHAFT
24	G00-0202	CLUTCH LEVER PLT B	62	F57-5601	DRIVE SHAFT WASHER
25	F79-3401	CLUTCH CAM RET	63	B55-0301	BUSHING B
26	B86-1702	BALL BEARING B	64	G02-2501	DRIVE SHAFT
27	F79-3501	CLUTCH CAM	65	G00-0801	DRIVE SHAFT RET
28	G00-0501	YOKE PLT	66	E13-4501	DRIVE SHAFT RET SCREW
29	F79-3801	CLUTCH CAM SCREW	67	F76-1701	A/R RATCHET
30	F79-4501	CLUTCH SPRING	68	G00-1501	DRIVE GEAR A
31	F79-4401	PIN A	69	G00-1601	DRIVE GEAR B
32	G00-0601	CLUTCH TRIP PLT	70	F79-6101	EARED WASHER
33	F79-4701	CLUTCH TRIP PLT SPRING	71	F96-7801	DRAG WASHER
34	F79-4601	PIN B	72	F79-6301	KEY WASHER A
35	371-6905	CLUTCH TRIP PLT WASHER	73	B36-0303	KEY WASHER B
36	320-1402	CLUTCH TRIP PLT RET	74	150-8901	DRAG SPRING WASHER
37	F79-4801	YOKE	75	G05-3001	GEAR SHAFT COLLAR
38	F79-4901	YOKE SPRING	76	F99-9801	ROLLER CLUTCH
39	F80-1501	PINION GEAR	77	G05-2801	DRAG COLLAR
40	E21-9701	BEARING RET C	78	G05-0601	STAR DRAG
41	F64-8301	BUSHING A	79	F85-0401	FRICTION WASHER
42	G05-0003	R/S PLT	80	G05-0701	HANDLE
43	B67-9304	R/S PLT SCREW	81	F84-9901	HANDLE NUT
44	F80-0501	PINION SHAFT	82	F85-0004	HANDLE NUT RET
45	171-5201	O RING B			