


SPINNING REEL MINISPIN-S500T



| Key No. | Parts No. | Parts Name |
|---------|-----------|-----------------------|
| 2-8 | G15-6001 | SPOOL |
| 1 | G15-6201 | DRAG KNOB |
| 2 | F66-7901 | DRAG WASHER RET |
| 3 | F66-7801 | KEY WASHER |
| 4 | F66-7701 | DRAG WASHER |
| 6 | F66-7601 | CLICK PAWL |
| 7 | 144-1211 | CLICK SPRING |
| 8 | B86-4101 | CLICK RET |
| 9 | F66-7001 | SPOOL WASHER |
| 10 | F66-6301 | MAIN SHAFT |
| 11 | E32-0601 | OSC SUPPORT |
| 12 | E15-0203 | OSC SUPPORT SCREW |
| 13 | 342-4001 | ROTOR NUT |
| 14 | F66-5104 | ROTOR |
| 15 | F66-5501 | BAIL TRIP LEVER |
| 16 | F66-5604 | BAIL TRIP COVER |
| 17 | 352-2501 | BAIL TRIP COVER SCREW |
| 18 | 352-2501 | LINE ROLLER SCREW |
| 19 | F66-5203 | BAIL ARM |
| 20 | 351-6101 | BAIL HOLDER SCREW |
| 21 | B55-4301 | LINE ROLLER WASHER |
| 22 | F66-6001 | LINE ROLLER |
| 23 | B45-1501 | LINE ROLLER COLLAR |
| 24 | F66-5702 | BAIL |
| 25 | E32-0201 | BAIL SPRING |

| Key No. | Parts No. | Parts Name |
|---------|-----------|-------------------|
| 26 | F66-5304 | BAIL SPRING COVER |
| 27 | B12-8701 | ROTOR WASHER |
| 28 | F66-5001 | BEARING RET |
| 29 | E15-7502 | BEARING RET SCREW |
| 30 | E18-2801 | BALL BEARING |
| 31 | F66-4901 | A/R RATCHET |
| 32 | F66-4801 | PINION GEAR |
| 33 | G15-5701 | BODY |
| 34 | F66-4501 | A/R CAM SPRING |
| 35 | F66-4401 | A/R LEVER |
| 36 | E15-3101 | A/R PAWL WASHER |
| 37 | F66-4601 | A/R PAWL |
| 38 | E03-3001 | A/R PAWL COLLAR |
| 39 | F66-4701 | A/R PAWL SPRING |
| 40 | B00-8601 | A/R PAWL SCREW |
| 41 | F66-6201 | A/R PAWL SPRING B |
| 42 | F66-6101 | DRIVE GEAR |
| 43 | F66-6501 | OSC SLIDER |
| 44 | 375-8500 | DRIVE GEAR WASHER |
| 45 | G15-5801 | SIDE COVER |
| 46 | E13-0501 | SIDE COVER SCREW |
| 47 | G15-5901 | HANDLE |
| 48 | F02-0201 | HANDLE WASHER |
| 49 | E03-5505 | HANDLE SCREW |