


CROSSFIRE 3550 / 4050



Key No.	Parts No.	Parts Name
5	W35-0601	SPOOL
6	W01-3501	MAIN SHAFT
8	W01-3201	ROTOR NUT
9	W35-1104	A/R PAWL SPRING A
10	W35-1204	SPRING HOLDER
11	W01-1201	BALL BEARING A
12	W35-1502	PINION GEAR
13	W35-1602	A/R PAWL SCREW
14	W35-2001	A/R PAWL
15	W35-2501	A/R PAWL SPRING B
16	W35-2901	A/R CAM
17	W00-2401	A/R CAM SPRING
18	W01-1501	BALL BEARING SCREW
19	W01-0501	A/R LEVER
20	W00-2201	A/R LEVER SCREW
21	W35-3303	BODY
22	W01-0201	DRIVE GEAR BUSHING
23	W01-0301	DRIVE GEAR
24	W01-0401	DRIVE GEAR WASHER
25	W01-1202	BALL BEARING B
26	W35-3503	SIDE COVER
27	W35-3803	HANDLE
28	W00-3901	HANDLE WASHER
29	W35-3903	HANDLE SCREW
30	W35-4001	OSC GEAR COLLAR
31	W00-9801	OSC GEAR
32	W00-9901	OSC SLIDER
33	W01-0001	OSC SLIDER RET
34	W01-0101	OSC SLIDER RET PLT SCREW
35	W00-3801	REAR COVER SCREW
36	W00-8601	DRAG WASHER A
37	W00-8701	CLICK GEAR
38	W00-8901	EARED WASHER
39	W00-9001	KEY WASHER
40	W00-8801	DRAG WASHER B
41	W00-9101	DRAG COIL SPRING
42	W35-4202	DRAG SCREW

Key No.	Parts No.	Parts Name
43	W35-4501	REAR COVER A
44	W35-4801	REAR COVER B
45	W35-4903	REAR COVER RET
46	W35-5201	DRAG KNOB
47	W35-5303	DRAG KNOB RET
48	W35-5403	O RING
49	W35-5703	ROTOR
50	W35-5903	BAIL HOLDER NUT
51	W35-6001	BAIL HOLDER SCREW
53	W01-5501	ROTOR NUT LOCK SCREW
54	W35-6103	BAIL TRIP LEVER
55	W35-6201	BAIL SPRING HOLDER
56	W35-6303	BAIL SPRING
57	W35-6403	BAIL SPRING SHAFT
58	W35-6503	BAIL TRIP COVER
59	W01-3001	BAIL TRIP COVER SCREW
60	W35-6803	BAIL ARM
61	W01-4101	BAIL ARM SCREW
62	W00-5401	LINE ROLLER COLLAR
64	W35-7201	BAIL
66	W35-7501	LINE ROLLER
67	W00-5501	LINE ROLLER SCREW
69	W00-3801	SIDE COVER SCREW
81	W35-8702	DRAG WASHER C

SPECIAL PART FOR CF4050

Key No.	Parts No.	Parts Name
5	W35-0701	SPOOL
6	W01-5601	MAIN SHAFT
9	W35-1105	A/R PAWL SPRING A
14	W35-2101	A/R PAWL
31	W01-5001	OSC GEAR
49	W35-5803	ROTOR
54	W35-6104	BAIL TRIP LEVER
58	W35-6504	BAIL TRIP COVER
64	W35-7301	BAIL
81	W35-8702	DRAG WASHER C