


LAGUNA 3500 / 4000



Key No.	Parts No.	Parts Name
1	G35-4801	DRAG KNOB
2	F37-3301	DRAG WASHER RET
3	F09-4901	KEY WASHER
4	373-3603	EARED WASHER
5	E13-6001	DRAG WASHER
2-9	G35-4601	SPOOL
2-9	G38-4201	SPOOL (EXTRA)
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	F09-4701	SPOOL WASHER
11	E46-2701	CLICK GEAR
12	G02-5701	MAIN SHAFT
13	G02-5501	OSC SLIDER
14	352-1505	OSC SLIDER SCREW
15	G12-3301	ROTOR NUT
16	G23-0204	ROTOR
17	G01-8601	LINE ROLLER SCREW
18	G19-4501	BAIL ARM
19	G22-4901	BAIL ARM SCREW
20	F89-7101	LINE ROLLER WASHER
21	G28-5701	BALL BEARING A
22	F62-5001	LINE ROLLER
23	351-6101	BAIL HOLDER SCREW
24	G35-4101	BAIL
25	G01-7502	BAIL SPRING SHAFT
26	G14-8601	BAIL SPRING
27	G01-7401	BAIL SPRING HOLDER
28	G23-0302	BAIL SPRING COVER
29	G20-5101	BAIL SPRING COVER SCREW
30	G19-5101	BAIL HOLDER NUT
31	G35-4301	BAIL HOLDER COVER
32	G19-4101	BAIL TRIP LEVER SPRING
33	G26-5501	BAIL TRIP LEVER
34	375-3002	BAIL TRIP LEVER WASHER A
35	375-3003	BAIL TRIP LEVER WASHER B
36	G19-3701	BAIL TRIP LEVER SCREW

Key No.	Parts No.	Parts Name
37	G33-2701	BEARING RET SCREW
38	G35-3701	BEARING RET
39	G35-3401	BALL BEARING B
40	G35-3601	BALL BEARING COLLAR
41	F64-1501	CLUTCH CAM RET
42	F64-1401	CLUTCH CAM
43	G35-3501	SPACING SLEEVE
44	G31-4501	ROLLER CLUTCH
45	G35-3401	BALL BEARING C
46	373-7814	PINION WASHER
47	G02-5301	PINION GEAR
48	G35-3301	BODY
49	G19-3103	A/R LEVER
50	G19-3301	A/R CAM SPRING
51	F13-1601	OSC GEAR COLLAR
52	G13-1700	OSC GEAR WASHER
53	F74-7801	OSC GEAR
54	G35-3901	REAR COVER A
55	G34-3701	REAR COVER SCREWA
56	G35-4001	REAR COVER B
57	G33-2701	REAR COVER SCREWB
58	631-6901	BALL BEARING D
59	G02-5601	DRIVE GEAR
60	373-7808	DRIVE GEAR WASHER
61	631-6901	BALL BEARING E
62	G35-3801	SIDE COVER
63	G33-2902	SIDE COVER SCREWA
64	G33-3002	SIDE COVER SCREWB
65	G35-4401	HANDLE
66	F72-1201	HANDLE COLLAR
67	F67-6509	HANDLE SCREW

SPECIAL PART FOR LA4000

Key No.	Parts No.	Parts Name
2-9	G35-5801	SPOOL
2-9	G38-4501	SPOOL (EXTRA)