



Part No.	Description
8501600	CROSS WIND GEAR
8501700	OSCILLATION SLIDE
8501800	OSCILLATION SLIDE CLIP
8501900	OSCILLATION SLIDE CLIP SCREW
8502000	BUSHING
8502100	BEARING RETAINER
8502200	BUSHING
8502300	ANTI-REVERSE BUTTON
8502400	ANTI-REVERSE SHAFT
8503100	O RING
8503200	O RING
8503300	HANDLE WASHER
8503400	BAIL ARM
8503500	BAIL ARM WASHER
8503600	LINE GUIDE
8503800	BAIL SCREW
8503900	HEX NUT LOCKING RING
8504300	BAIL ARM SCREW
8504600	BAIL SPRING
8504700	BAIL SPRING RETAINER
8504800	BAIL SPRING PIN
8504900	TRIP LEVER
8505000	HEX NUT
8505100	DRAG COUNTER TAPE
8505300	ANTI-REVERSE SPRING
8505400	RETAINER SCREW
8505500	HANDLE BALL BEARING
8505600	DRIVE GEAR SHIM
8505800	DRAG CLICK SPRING
8505900	MOUNTING SCREW
8506300	DRAG WASHER RETAINER
8506600	DRAG HUB
8506700	WASHER

Part No.	Description
8506800	RETAINER CLIP
8506900	DRAG KNOB
8507000	DRAG KNOB SCREW
8507100	DRAG CLICK
8507200	DRAG CLICK SPRING
8507300	DRAG KNOB COVER
8507400	DRAG COVER
8507500	DRAG COUNTER WINDOW
8507600	HANDLE CAP SCREW
8507900	COVER PLATE SCREW
8508300	CAP SCREW WASHER
8508800	HANDLE KNOB SCREW
8509000	HANDLE ARM
8509200	HANDLE KNOB
8509300	HANDLE KNOB COVER
8509600	DRAG ASSEMBLY
8509900	BUSHING
8510300	BAIL COVER
8510900	DRAG COVER SCREW
8511000	WASHER
8511400	DRIVE GEAR
8511500	PINION
8511600	ANTI-REVERSE FRICTION SPRING
8512100	ROTATING HEAD
8512300	AXEL
8512400	BAIL WIRE ASSEMBLY
8512700	ANTI-REVERSE DOG
8512800	COUNTERWEIGHT
8516000	FRICTION SPRING RETAINER
8518300	HANDLE
8549500	STANDARD SPOOL
8549600	HOUSING
8549700	SIDE PLATE