



Part No.	Description
8429300	BAIL ARM SCREW
8429900	ROTATING HEAD HEX NUT
8502000	CROSS WIND BUSHING
8502700	LINE CLIP
8502800	RETAINING CLIP
8503300	HANDLE KNOB WASHER
8503800	LINE GUIDE SCREW
8503900	HEX NUT LOCKING RING
8505300	ANTI-REVERSE SHAFT SPRING
8505500	BALL BEARING
8505600	SHIM - DRIVE GEAR
8505900	MOUNTING SCREW
8508300	CAP SCREW WASHER
8508800	HANDLE KNOB SCREW
8549800	HANDLE KNOB
8590300	DRIVE GEAR
8590500	CROSS WIND GEAR
8590600	OSCILLATION SLIDE
8590700	OSCILLATION SLIDE SCREW
8590800	BEARING RETAINER
8591200	ANTI-REVERSE SHAFT
8592100	ANTI-REVERSE FRICTION
8592600	SPOOL CLICK
8592700	SPOOL SPINDLE
8593000	EARED DRAG WASHER
8593100	KEYED DRAG WASHER
8593200	DRAG WASHER
8593300	DRAG RETAINER
8593900	BASE DRAG WASHER
8594500	HOUSING BUSHING
8595700	SIDE PLATE SCREW
8596000	RETAINING SCREW

Part No.	Description
8611500	AR FRICTION BUSHING
8611600	AR FRICTION WASHER
8790900	LEVER SPRING
8791300	BAIL SCREW
8791400	RACK
8791800	BAIL SPRING
8792200	LINE GUIDE RACE
8792400	STOP RACK
8793000	HOUSING
8793100	SIDE PLATE
8793200	ROTATING HEAD
8793400	LEVER SPRING
8793500	PARTITION PLATE
8793600	RACK COVER PLATE
8794100	BAIL ARM LEVER
8794200	BAIL LOCK
8794300	BAIL ARM COVER PLATE
8794500	ANTI-REVERSE DOG
8794600	PINION GEAR
8794700	ROT HEAD CNTRWEIGHT
8794900	BAIL WIRE
8795000	TRIP LEVER
8795100	BAIL ARM
8795200	AXLE
8795300	SPOOL
8795400	BAIL MOUNT
8795500	ANTI-REVERSE BUTTON
8795600	HANDLE ARM
8795700	HANDLE
8795800	DRAG KNOB
8795900	LINE GUIDE
8819200	HANDLE CAP SCREW W/WASHER