



Item	number	Description	Item	number	Description
1	888-8488	LEFT SIDE COVER ASSEMBLY	32	888-8528	HANDLE ASSEMBLY
2	888-8489	CONTROL DIAL	33	888-8529	HANDLE NUT LOCK CAP
3	888-8490	DIAL FRICTION RING	34	888-8530	HANDLE NUT LOCK SCREW
4	888-8491	SLIDE CAM	35	888-8531	THUMB SCREW (3)
5	888-8492	SLICE CAM SPRING	36	888-8532	HANDLE SPRING WASHER
6	888-8493	SPOOL COVER	37	888-8533	RIGHT SIDE COVER SCREW (2)
7	888-8494	SPOOL TENSION SHIM	38	888-8534	RIGHT SIDE COVER
8	888-8495	BALL BEARING	39	888-8535	BEARING WASHER (2)
9	888-8496	MAGNET PLATE ASSEMBLY	40	888-8536	SPRING "D" WASHER (2)
10	888-8497	SPOOL ASSEMBLY	41	888-8537	DRAG WASHER
11	888-8498	BALL BEARING	42	888-8538	DRAG DISC WASHER
12	888-8499	THUMB BAR	44	888-8539	CRANK SHAFT
13	888-8509	THUMB BAR CAM	45	888-8540	CRANK SHAFT RETAINER
14	888-8510	RELEASE SLIDER	46	888-8541	OSCILLATING GEAR
15	888-8511	RELEASE SLIDER SPRING	47	888-8542	PAWL CAP
16	888-8512	RELEASE SLIDER SCREW	48	888-8543	LINE GUIDE PAWL
17	888-8513	E-CLIP	49	888-8544	LINE GUIDE CARRIER ASSEMBLY
18	888-8514	PNION YOKE	50	888-8545	CARRIER GUIDE
19	888-8515	YOKE SPRING	51	888-8546	WORM SHAFT
20	888-8516	PNION ASSEMBLY	52	888-8547	MAGNET PLATE SCREW (2)
21	888-8517	STAR TRIP LATCH	55	888-8548	FRAME
22	888-8518	RING TRIP LATCH	56	888-8557	CRANK SHAFT B/B
23	888-8519	RATCHET WASHER	57	888-8558	HANDLE NUT
24	888-8520	RATCHET	58	888-8559	HOOD
25	888-8521	DRIVER GEAR WASHER	59	888-8560	THUMB BAR SPRING
26	888-8522	DRIVE GEAR	60	888-8561	ONE-WAY CLUTCH
27	888-8523	BALL BEARING	61	888-8562	CLUTCH BUSH
28	888-8524	TENSION KNOB O-RING	62	888-8563	FLIPPING LEVER
29	888-8525	TENSION KNOB WASHER	63	888-8564	THRUST WASHER
30	888-8526	TENSION KNOB	64	888-8565	TENSION RUBBER WASHER
31	888-8527	STAR DRAG	65	888-8565	FIXED PIN