



PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
8505500	BALL BEARING	8643100	TRIP LEVER SPRING PIN
8507600	HANDLE CAP SCREW W/ WASHER	8643200	TRIP LEVER SCREW W/BUSHING
8508300	CAP SCREW WASHER	8643300	KEYED WASHER
8640000	HOUSING	8643400	ROTATING HEAD NUT
8640100	SIDE PLATE	8643500	KEYED SPACER WASHER
8640600	ANTI-REVERSE BUTTON	8643600	PINION GEAR W/RATCHET
8640800	ROTATING HEAD	8643700	BEARING RETAINER
8641100	DRAG KNOB	8643800	BEARING RETAINER SCREW
8641200	DRAG RETAINER	8643900	ANTI-REVERSE DOG
8641300	KEYED DRAG WASHER	8644000	ANTI-REVERSE DOG SCREW W/BUSHING
8641400	DRAG WASHER	8644100	ANTI-REVERSE LEVER
8641500	EARED DRAG WASHER	8644200	HOUSING BUSHING
8641600	BASE DRAG WASHER	8644300	SIDE PLATE BUSHING
8641700	CLICK GEAR	8644500	ANTI-REVERSE FRICTION SPRING
8641800	AXLE	8644700	SIDE PLATE SCREW
8641900	BAIL ARM	8644800	HANDLE
8642000	BAIL RETAINING PIN	8644900	SPOOL
8642100	RETAINING PIN CLIP	8645300	AXLE W/CLICK GEAR
8642200	LINE GUIDE SCREW	8646600	SPOOL CLICK
8642300	LINE GUIDE RACE	8646700	SPOOL CLICK SPRING
8642400	LINE GUIDE	8646800	SPOOL CLICK SCREW
8642500	BAIL WIRE W/MOUNT	8647100	SHIM-DRIVE GEAR
8642600	COVER PLATE N1&N2	8647300	CROSS WIND GEAR BUSHING
8642700	COVER PLATE SCREW	8647400	CROSS WIND GEAR
8642800	BAIL SPRING	8647500	OSCILLATION SLIDE
8642900	TRIP LEVER	8647600	OSCILLATION SLIDE SCREW
8643000	TRIP LEVER SPRING	8647700	DRIVE GEAR