



Part No.	Description
8293100	ROTATING HEAD BALLBEARING
8319000	OIL DUST SHIELD
8321100	SHIM - DRIVE GEAR
8429300	BAIL ARM SCREW
8460400	SIDE PLATE SCREW
8505300	ANTI-REVERSE SHAFT SPRING
8505400	RETAINER SCREW
8505900	MOUNTING SCREW
8508300	CAP SCREW WASHER
8651600	BAIL SPRING PIN
8666700	LINE GUIDE
8667700	LINE GUIDE WASHER
8667800	LINE GUIDE BUSHING
8670300	DRIVE GEAR
8670400	PINION GEAR
8670600	OSCILLATION SLIDE
8670700	BEARING RETAINER
8671000	ANTI-REVERSE SHAFT
8671500	TRIP LEVER
8671700	BAIL SPRING
8672000	ANTI-REVERSE FRICTION
8672100	DRIVE GEAR BUSHING
8672200	ANTI-REVERSE DOG
8673100	ANTI-REVERSE BUSHING
8673200	ROTATING HEAD WASHER
8673600	OSCILLATION SLIDE SCREW
8674200	BEARING
8675100	BUTTON & CLICK SCREW

Part No.	Description
8676100	LINE GUIDE SCREW
8676200	HEX NUT RETAINER
8676400	BEARING WASHER
8676800	LINE GUIDE RACE
8680200	RETAINER SCREW
8683000	CROSS WIND GEAR
8683600	DRAG WASHER
8684000	BASE DRAG WASHER
8684300	SPOOL GEAR
8684900	FREE SPOOL CLICK
8685000	SPOOL CLICK
8685100	HEX NUT
8685400	FREE SPOOL FRICTN SCREW
8685600	AXLE
8685800	DRAG KNOB W/WASHER
8685900	SPOOL SPINDLE
8686000	SPOOL
8686200	FREE SPOOL FRICTION & SPRING
8686400	BAIL WIRE W/ COVER PLATE
8815200	ANTI-REVERSE BUTTON
8815600	BAIL ARM
8815700	ROTATING HEAD
8815800	COVER PLATE
8815900	HANDLE CAP SCREW W/WASHER
8816200	HANDLE
8817500	HOUSING
8817600	SIDE PLATE