



Item	Part Number	Description	Item	Part Number	Description
1	888-8138	SCREW	29	888-8306	RATCHET GEAR ASSEMBLY
2	888-8139	RETAINING CUP ASSEMBLY	30	888-8167	RATCHET AXIS
3	888-8140	HANDLE RETAINING NUT	31	888-8168	WASHER
4	888-8141	HANDLE ASSEMBLY	32	888-8169	SUPPORT RING
5	888-8142	WASHER	33	888-8170	ANTI-REVERSE CLAW AXIS
6	888-8143	STAR DRAG ASSEMBLY	34	888-8171	ANTI-REVERSE CLAW
7	888-8144	SCREW	35	888-8172	ANTI-REVERSE CLAW SPRING
8	888-8145	WASHER	36	888-8173	TRAVERSE CAM GEAR
9	888-8146	CLUTCH LEVER B	37	888-8174	E-RING
10	888-8302	SIDE PLATE SCREW	38	888-8175	BUSHING
11	888-8303	RIGHT SIDE PLATE	39	888-8176 (50LW 888-8177)	TRAVERSE CAM
12	888-8304	LINE HOLDER	40	888-8178	E-RING
13	888-8150	CLUTCH LEVER A	41	888-8307 (50LW 888-8308)	MAIN BODY ASSEMBLY
14	888-8151	SPRING	42	888-8181	LINE GUIDE CAP
15	888-8152	BRAKE PIECE	43	888-8182	TRAVERSE CLAW
16	888-8305	PINION GEAR ASSEMBLY	44	888-8183 (50LW 888-8184)	SUPPORT BAR
17	888-8154	CLUTCH SPRING	45	888-8309	LINE GUIDE HOLDER ASSY.
18	888-8155	CLUTCH BAR	46	888-8186 (50LW 888-8187)	TRAVERSE CAM PIPE
19	888-8156	CLUTCH CAM	47	888-8310 (50LW 888-8311)	SPOOL ASSEMBLY
20	888-8157	BUSHING	48	888-8281 (50LW 888-8282)	LEFT SIDE PLATE
21	888-8158	SPRING WASHER	49	888-9283	BRAKE SPRING
22	888-8159	SEALED BUSHING	50	888-8284	BRAKE PIECE
23	888-8160	DRAG SPRING	51	888-8285	BRAKE ADJUSTMENT KNOB
24	888-8161	DRAG WASHER	52	888-8149	ANTI-REVERSE SWITCH
25	888-8162	DRAG WASHER	53	888-8207	WASHER
26	888-8163	MAIN GEAR	54	888-8208	BRAKE PIECE
27	888-8164	DRAG WASHER	55	888-8209	WASHER
28	888-8165	DRAG WASHER			