



Part No.	Description
8429300	BAIL ARM SCREW
8502700	LINE CLIP
8502800	RETAINING CLIP
8503800	LINE GUIDE SCREW
8503900	HEX NUT LOCKING RING
8505000	HEX NUT
8505300	ANTI-REVERSE SHAFT SPRING
8505400	RETAINER SCREW
8505500	BALL BEARING
8505600	SHIM - DRIVE GEAR
8505900	MOUNTING SCREW
8507900	SIDE PLATE SCREW
8508300	CAP SCREW WASHER
8514900	BAIL SPRING PIN
8592400	BEARING
8592600	SPOOL CLICK
8593000	EARED DRAG WASHER
8593100	KEYED DRAG WASHER
8593200	DRAG WASHER
8593300	DRAG RETAINER
8593900	BASE DRAG WASHER
8596000	RETAINING SCREW
8598200	DRAG INDEX RETAINER
8599300	RETAINING CLIP
8610500	TRIP LEVER
8610800	ANTI-REVERSE SHAFT
8611500	AR FRICTION BUSHING
8611600	AR FRICTION WASHER
8615700	ANTI-REVERSE DOG
8615800	OSCILLATION SLIDE
8616000	ANTI-REVERSE FRICTION
8616100	PINION GEAR
8616200	WORM SHAFT DRIVE GEAR
8616300	WORM SHAFT PINION

Part No.	Description
8616400	BEARING RETAINER
8616500	WORM SHAFT BUSHING
8616600	WORM SHAFT BUSHING
8616700	PAWL RETAINER
8616800	DRIVE GEAR
8616900	WORM SHAFT
8617000	OSCILLATION PAWL
8617100	PAWL WASHER
8617200	OSC SLIDE RETAINER
8617300	WORM SHAFT WASHER
8617400	EARED WASHER
8617500	BEARING WASHER
8617600	OSCILLATION SLIDE SCREW
8617700	PAWL BUSHING
8618400	DRAG INDEX
8618800	AXLE
8619000	BEARING
8620600	SPOOL SPINDLE
8656600	HANDLE CAP SCREW
8657500	DRAG KNOB
8657700	SPOOL
8657800	BAIL ARM
8657900	BAIL WIRE W/COVER PLATE
8658000	ROTATING HEAD
8658100	COVER PLATE
8658200	ANTI-REVERSE BUTTON
8658300	HOUSING
8658400	SIDE PLATE
8658500	HANDLE
8664100	BAIL SPRING
8666700	LINE GUIDE
8667700	LINE GUIDE WASHER
8667800	LINE GUIDE BUSHING
8676800	LINE GUIDE RACE