



Key No.	Part No.	Description	Price	Key No.	Part No.	Description	Price
1	001 030SN	Right-Side Plate Assembly	\$80.00	59	059 050	Slotted Washer	\$.80
2	002 030	Quadrant Ring	5.65	60	060 050	Backing Washer	.90
4	004 030	Cam Thrust Washer	.95	62	062 050	Click Spring	.80
5H	005 030HS	Main Gear High Speed	17.00	63	063 030T	Stand Screw (4 req.)	.80
5L	005 030LS	Main Gear Low Speed	18.50	63A	063 349	Hold Down Screw	.80
6	006 155	Spacer Washer	.60	63B	063 050	Long Screw	.75
7	007 030	Metal Drag Washer	7.75	63C	063A050	Screw	1.25
13	013 030SW	Pinion Gear	32.00	69	069 050	Locating Pin (2 req.)	1.20
14	014 050	Dog Spring (2 req.)	1.00	69B	069B050	Retaining Ring (2 req.)	.80
15	015 050	Dog (2 req.)	.80	81	081 050	Ratchet	5.15
18	018 030T	Disc Clutch Spring (4 req.)	.85	91	091N050	Handle Rivet	2.50
19	019 020	Eccentric Cam	12.50	95	095 050	Click Tongue Bushing	2.05
20	020L704	Ball Bearing (3 req.)	14.00	95A	095A020	Click Bushing Washer	.65
21	021 030S	Eccentric Lever	6.00	95B	095B 710	Click Bushing Nut	.50
22	022 109	Dog Spring Screw (2 req.)	.55	95C	095A050	Click Bushing Washer	.65
23	023 050S	Handle Screw	3.70	98	098 030SN	Bridge Bushing	5.10
24	024 030TW	Handle Complete	17.00	101	101 030	Drive Plate Screw (8 req.)	.45
24A	024 030TW-1	Handle Blank Only	6.40	110	110 050	Handle Lock Screw	.50
24C	024C050	Handle Knob Cap	1.25	110A	110A050	Handle Locking Plate	2.40
25	025 050	Handle Knob	6.00	112	112 050	Eccentric Lever Knob	16.25
26	018 349	Gear Stud Spring	.45	112A	112A050	Eccentric Knob Screw	.90
27	027 030T	L.S. Plate Assembly	60.00	113	113 050	Eccentric Lever Cap	3.95
29	029L030TW	Spool	73.95	117	117D030	Drive Plate w/ Drag Washer	15.00
30	030 020T	Stand	18.70	119	119 030S	Coupling Plate	1.10
31	031 020	Short Quadrant Screw	.55	123	123 050	Drag Cover Screw (4 req.)	.45
31A	031T080	Frame Screw (7 req.)	.55	124	124 030S	Bridge Cover	5.90
32	032 014CH	Center Quadrant Screw	.40	*	*125 030S	Cam Housing	7.50
33	033 114	Rod Clamp	5.30	134	134 050S	Gear Stud	9.50
*	*033R114	Ringed Rod Clamp (Optional)	9.95	141	141 030	Cam Follower	5.65
34	034 050T	Clamp Screw (2 req.)	2.05	142	142 050	Cam Follower Pin (2 req.)	.60
34C	034C050T	Rod Clamp Screw w/Nut	3.40	143	143 030	Adjusting Screw	4.00
35	035 050N	Click Tongue	3.10	144	144 050	Preset Knob	6.95
36	036 050	Click Button	7.00	152A	152A050T	Rod Clamp Acorn Nut (2 req.)	1.35
36A	036 700	Click Button Nut	.90	156	156 030T	Drag Cover	5.05
36S	036S080ST	Click Button Cap	.40	157	157 050	Quadrant Spacer Bushing (2 req.)	.60
38	101 050S	Coupling Plate Screw (3 req.)	.45	161	161 050	Locating Pin Bushing (2 req.)	1.20
38A	038T050	Frame Screw (2 req.)	.50	162	162 050	Locating Pin Spring (2 req.)	.50
38B	038T080	Long Quadrant Screw	.55	171	171 050S	Plunger	3.00
38B	038T080	Long Quadrant Screw	.55	172	172 050S	Plunger Cap	2.70
39A	039A080S	Cover Screw (3-Req.)	.45	172A	172A050S	Plunger Pin (2 req.)	.60
41	041 050	L.S. Bearing Spring	.90	173	173 050S	Gear Retainer (2 req.)	1.35
50	050 030S	Shield	2.10	183	183 030SW	Tube Frame	95.00
54	054 030T	Harness Lug (2 req.)	2.45	264	264 030T	Stand Gasket	1.60
55	055 080	Ball Bearing	16.00				
Note:	3-30S Bridge	Use For OLD STYLE R.S. Plate	17.25				