



Key No.	Part No.	Description	Price	Key No.	Part No.	Description	Price
1	001 050TN	Right Side Plate Assembly	\$94.00	41	041 050	L.S. Bearing Spring	\$.90
2	002 050	Quadrant Ring	7.05	54	054 050T	Harness Lugs (2 req.)	2.90
4	004 050	Cam Thrust Washer	.90	55	055 050	Spool Bearings (3 req.)	15.00
5	005 050	Main Gear (50T)	12.30	55A	055 080	L.S. Bearing	16.00
	005 050W	Main Gear	12.30	59	059 050	Slotted Washer	.80
6	006 155	Spacer Washer	.60	60	060 050	Backing Washer	.90
7	007 050	Metal Drag Washer	9.00	62	062 050	Click Spring	.80
9	009 030	Spacing Sleeve	.70	63	063 030T	Stand Screw (4 req.)	.80
13	013 050	Pinion Gear	26.25	63A	063 050	Screw	.75
	013 050W	Pinion Gear	28.00	63B	063A050	Long Screw	1.25
14	014 050	Dog Spring (2 req.)	1.00	69	069 050	Locating Pins (2 req.)	1.20
15	015 050	Dog (2 req.)	.80	69B	069B050	Retaining Rings (2 req.)	.80
18	018 050W	Disc Clutch Springs (2 req.)	.90	81	081 050	Ratchet	5.15
18A	018 050TW	Disc Clutch Springs (2 req.)	.90	91	091N050	Handle Rivet	2.50
19	019 050W	Eccentric Cam	13.00	95	095 050	Click Bushing	2.05
21	021 050	Eccentric Cam Lever	6.00	95A	095A020	Click Bushing Washer	.65
22	022 109	Dog Spring Screw (2 req.)	.55	95B	095A050	Click Bushing Washer	.65
23	023 114	Handle Screw	2.65	*	098 050TN	Bridge Bushing	3.80
24	024 050T	Handle	17.00	101	101 030	Drive Plate Screws (8 req.)	.45
24A	024 050T-1	Handle Blank Only	6.40	110	110 050	Handle Lock Screw	.50
24C	024C050	Handle Knob Cap	1.25	110A	110A050	Handle Locking Plate	2.40
25	025 050	Handle Knob	6.00	112	112 050	Eccentric Lever Knob	16.25
27	027 050T	Left Side Plate	73.00	112A	112A050	Eccentric Knob Screw	.90
29	029L050T	Spool	93.00	113	113 050	Eccentric Lever Cap	3.95
	029L050TW	Spool	98.00	117	117D050	Drive Plate w/ Drag Washer	17.50
30	030 050T	Stand	21.00	119	119 050	Main Gear Plate	1.35
31	031T020	Short Quadrant Screw	.55	123	123 050	Drag Cover Screws (4 req.)	.45
32	032 014CH	Center Quadrant Screw	.40	124	124 050	Bridge Cover	5.90
33	033 114	Rod Clamp	5.30	*	125 050	Cam Housing	7.50
*	033R114	Ringed Rod Clamp (Optional)	9.95	134	134 050	Gear Stud	6.50
34	034 050T	Clamp Screw (2 req.)	2.05	134A	134A050	Gear Stud Washer	.90
34C	034C050T	Rod Clamp Screw w/ Nut	3.40	141	141 050	Cam Follower	5.75
35	035 050N	Click Tongue	3.10	142	142 050	Cam Follower Pins (2 req.)	.60
36	036 050	Click Button	7.00	143	143 050	Adjusting Screw	4.25
36A	036 700	Click Tongue Nut	.90	144	144 050	Pre-Set Knob	6.95
36S	036S080ST	Click Button Cap	.40	152A	152A050T	Rod Clamp Acorn Nuts (2 req.)	1.35
38	038T050	Frame Screw (9 req.)	.50	156	156 050	Drag Cover	5.05
38A	038 710	Click Bushing Nut	.50	157	157 050	Quadrant Bushing (2 req.)	.60
38B	038 007	Coupling Plate Screw (3 req.)	.40	161	161 050	Locating Pin Bushing (2 req.)	1.20
38C	038 080	Long Quadrant Screw	.60	162	162 050	Locating Pin Springs (2 req.)	.50
39	039A080S	Bridge Cover Screw (3 req.)	.45	183	183 050T	Tube Frame	96.25
NOTE:	3-50	Bridge Use For OLD STYLE R.S. Plate	17.25	183 050TW	Tube Frame	105.50	
				264	264 030T	Stand Gasket	1.60