



SHIMANO®

1989 REPAIR MANUAL

Shimano American Corporation, One Shimano Dr.
Irvine, CA 9271



1989 Model



EXPLODED PARTS VIEW

SUPER
Bantam SpeedMaster
2000ULS

PARTS LIST

PART # DESCRIPTION

BNT 0009 Spacer (A)
BNT 0015 Drag Spring Washer
BNT 0016 Friction Washer (C)
BNT 0031 Spool Shaft Bearing
BNT 0042 Line Guide Pawl
BNT 0060 Spacer (Optional)
BNT 0124 Spool Shaft Bearing
BNT 0133 Worm Shaft Retainer
BNT 0151 Pawl Cap
BNT 0184 Magnet Retainer Lock
BNT 0188 O Ring
BNT 0194 Ball Bearing
BNT 0267 Cast Control Cap
BNT 0291 Side Plate Screw
BNT 0345 Drive Shaft Washer "B"
BNT 0425 Clutchbutton Lock
BNT 0489 Key Washer "A"
BNT 0490 Drag Washer
BNT 0493 Anti-Reverse Ratchet
BNT 0583 Drive Shaft Bearing
BNT 0596 Retractor Spring
BNT 0598 Bushing
BNT 0604 Yoke Spring
BNT 0605 Yoke
BNT 0609 Drive Shaft Retainer Screw

PART # DESCRIPTION

BNT 0612 Anti-Reverse Pawl Pin
BNT 0613 Anti-Reverse Pawl
BNT 0660 Spring Spacer
BNT 0661 Magnet Retainer Spring
BNT 0664 Spacer (B)
BNT 0706 Magnet Retainer
BNT 0720 Handle Nut Plate Screw
BNT 0723 Friction Washer "A"
BNT 0724 Pre-Set Dial
BNT 0725 Pre-Set Nut
BNT 0726 Pre-Set Spring
BNT 0727 Strike
BNT 0728 Pre-Set Washer
BNT 0729 Strike Spring
BNT 0730 Strike Ball
BNT 0731 Star Drag
BNT 0732 Drive Shaft Cam
BNT 0766 Dial Friction Washer
BNT 0816 Drive Shaft Washer
BNT 0817 Multi Purpose Screw
BNT 0822 Retractor Spring Pin
BNT 0825 Yoke Plate Washer (A)
BNT 0831 Line Guide
BNT 0837 Dial Cace
BNT 0838 Magnetic Control Dial

PART # DESCRIPTION

BNT 0862 Stabilizer Bar
BNT 0863 Level Wind Protector
BNT 0865 Level Wind Guard
BNT 0868 Left Side Plate Screw
BNT 0940 Drive Shaft Retainer
BNT 0956 Handle Nut Plate
BNT 0957 Handle Nut
BNT 0958 Handle Assembly
BNT 0960 Drive Gear
BNT 0961 Key Washer "B"
BNT 0964 Pinion Gear
BNT 0979 Right Side Plate
BNT 0980 Idle Gear (C)
BNT 0981 Drive Shaft
BNT 0982 Idle Gear (D) Screw
BNT 0983 Idle Gear (D)
BNT 0984 Multi Purpose Washer
BNT 0985 Worm Shaft
BNT 0986 Worm Bearing (A)
BNT 0987 Stabilizer Bar Screw
BNT 0988 Idle Gear (D) Nut
BNT 0989 One-Piece Frame
BNT 0990 Clutch Button
BNT 0991 Spool
BNT 0992 Left Side Plate

Prices and specifications subject to change without notice.

OCTOBER, 1988