


## ■ CALCUTTA ■ 400 95



CT400

Part #	Description	Part #	Description	Part #	Description
BNT0032	Bearing Retainer	BNT1573	Star Drag	BNT1638	Brake Collars (Gray - 6 Pieces)
BNT0042	Line Guide Pawl	BNT1612	Handle Assembly	BNT1639	Idle Gear (A) / Click Gear
BNT0060	Spacer (optional)	BNT1613	Drag Spring Washer	BNT1640	Forged One - Piece Frame Ass.
BNT0194	Ball Bearing	BNT1614	Cast Control Cap Assembly	BNT1641	Left Side Plate Bolt
BNT0425	"E" Lock	BNT1615	Right Side Plate Bolts Assembly	BNT1642	Clutch Bar Guide (A)
BNT0623	Click Switch Screw	BNT1616	Right Side Plate Screw	BNT1643	Clutch Bar Support
BNT0686	"E" Lock	BNT1617	Right Side Plate	BNT1644	Clutch Bar Guide (B)
BNT0799	Friction Washer	BNT1618	Key Washer (C)	BNT1645	Quick - Fire II Clutch Bar
BNT0819	Drive Shaft Bushing	BNT1619	Drag Washer (C)	BNT1646	Left Side Plate Screw (long)
BNT1133	Yoke Spring	BNT1620	Eared Washer	BNT1647	Idle Gear Washer
BNT1201	Retractor Spring Collar	BNT1621	Drag Washer (B)	BNT1648	Idle Gear (B)
BNT1206	Roller Clutch Inner Tube	BNT1622	Key Washer (A)	BNT1649	Idle Gear Shaft
BNT1207	Roller Clutch Bearing	BNT1623	Drive Gear	BNT1650	Brake Ring
BNT1215	Anti-Reverse Ratchet	BNT1624	Drag Washer (A)	BNT1651	Click Shaft
BNT1223	Retractor Spring	BNT1625	Drive Shaft	BNT1652	Click Plate Screw
BNT1227	Clutch Pawl Spring Retainer	BNT1626	Pinion Gear	BNT1653	Click Plate
BNT1230	Drive Shaft Spacer	BNT1627	Yoke	BNT1654	Click Link
BNT1237	Multi-Purpose Screw	BNT1628	Clutch Cam Retainer	BNT1655	Click Spring
BNT1239	Pawl Cap	BNT1629	Clutch Cam	BNT1656	Click Pawl
BNT1240	Line Guide	BNT1630	Set Plate	BNT1657	Click Switch Spring
BNT1245	Clutch Bar Support Spacer	BNT1631	Clutch Plate	BNT1658	Click Switch
BNT1293	Retractor Spring Pin	BNT1632	Worm Shaft Assembly	BNT1659	Click Switch Washer
BNT1302	Clutch Cam Screw	BNT1633	Level Wind Guard	BNT1660	Spacer (B)
BNT1306	Clutch Pawl	BNT1634	Level Wind Guide	BNT1661	Left Side Plate
BNT1307	Clutch Pawl Spring	BNT1635	Worm Bearing (A) Retainer		
BNT1337	Spacer	BNT1636	Left Side Plate Screw (short)	BNT1662	Brake Collars (Clear - 6 Pieces)
BNT1494	Drive Shaft Washer (B)	BNT1637	Spool Assembly		