


TRINIDAD™

TN 20⁰⁰



Part No.	Description
TGT0033	Drive Shaft Retainer
TGT0058	Spacer(B)
TGT0062	Click Pawl Retainer
TGT0065	Spacer (A)
TGT0111	Click Gear Retainer
TGT0112	Ball Bearing
TGT0128	Handle Nut Plate Screw
TGT0182	Cast Control Spacer (A)
TGT0185	IO Ring
TGT0257	Brake Collar
TGT0261	Handle Nut Plate
TGT0262	Handle Nut
TGT0263	Handle Assembly
TGT0264	Drive Shaft Shield
TGT0265	Star Drag
TGT0266	Star Drag Washer
TGT0267	Drag Spring Washer (9L)
TGT0268	Drag Spring Washer (9H)
TGT0269	Bearing Thrust Washer
TGT0270	Bearing Seal
TGT0271	Ball Bearing
TGT0272	Right Side Plate Screw (D)
TGT0273	Right Side Plate Screw (C)
TGT0274	Right Side Plate Screw (A)
TGT0275	Right Side Plate
TGT0276	Cast Control Cap
TGT0277	Cast Control Spacer (B)
TGT0278	Clutch Lever
TGT0279	Smoother
TGT0280	Line Clip
TGT0281	Roller Clutch Bearing
TGT0282	Eccentric Cam Bushing
TGT0283	Clutch Spring

Part No.	Description
TGT0284	Clutch Cam
TGT0285	Clutch Lever Screw
TGT0286	Roller Clutch Inner Tube
TGT0287	Key Washer
TGT0288	Drag Washer (D)
TGT0289	Eared Washer (E)
TGT0290	Key Washer (C)
TGT0291	Drag Washer (B)
TGT0292	Drive Gear
TGT0293	Drag Washer (A)
TGT0294	Anti-Reverse Ratchet
TGT0295	Click Pin
TGT0296	Click Spring
TGT0297	Drive Shaft
TGT0298	Drive Shaft Washer (B)
TGT0299	Yoke Spring
TGT0300	Yoke
TGT0301	Pinion Gear
TGT0302	Yoke Plate
TGT0303	Anti-Reverse Pawl
TGT0304	Set Plate Screw (B)
TGT0305	Multi-Purpose Screw
TGT0306	Anti-Reverse Pawl Keeper
TGT0307	Set Plate
TGT0308	Set Plate Screw (A)
TGT0309	Ball Bearing
TGT0310	Drive Shaft Washer (A)
TGT0311	One-Piece Frame
TGT0312	Brake Shaft Holder Screw
TGT0313	Brake Shaft Holder
TGT0314	Spool Assembly
TGT0315	Click Gear
TGT0316	Spool Shaft Spacer

Part No.	Description	
TGT0317	IBRi Gear (A)	
TGT0318	Bearing Retainer	
TGT0319	IBRi Cam Pin	
TGT0320	IBRi Cam	
TGT0321	IBRi Friction Washer	
TGT0322	IBRi Washer (C)	
TGT0323	IBRi Washer (A)	
TGT0324	IBRi Gear (C)	
TGT0325	IBRi Washer (B)	
TGT0326	Click Pawl Spring	
TGT0327	IBRi Set Plate	
TGT0328	IBRi Set Plate Screw	
TGT0329	Spacer (B)	
TGT0330	Click Pawl	
TGT0331	Click Pawl Spacer	
TGT0332	Click Spring Retainer	
TGT0333	Click Spring	
TGT0334	Click Spring Holder	
TGT0335	IBRi Click Pin	
TGT0336	IBRi Click Spring	
TGT0337	Left Side Plate Screw	
TGT0338	IBRi Washer (D)	
TGT0339	IBRi Dial	
TGT0340	Left Side Plate	
TGT0341	Click Button	
TGT0348	Spacer (C)	
TGT0351	Rod Clamp Bolt	(accessory)
TGT0352	Rod Clamp Nut (B)	(accessory)
TGT0353	Rod Clamp	(accessory)
TGT0354	Rod Clamp Nut (A)	(accessory)
TGT0355	Wrench	(accessory)