




RB3



KEY NO.	PART NO.	DESCRIPTION	PRICE	KEY NO.	PART NO.	DESCRIPTION	PRICE
1	JX323-01	Left Side Cover Assy	13 60	33	XX050-01	Screw - Release Slider	0 15
2	XX038-02	Spool Shaft Washer	0 21	34	JX339-01	Release Slider Assy	2 01
3	XX106-01	Bushing - Spool Shaft	0 88	35	JX102-01	Post - Kick Lever Guide	0 98
4	JX080-01	Clip Ring	0 26	36	JX008-01	Crank Shaft	3 30
5	JX321-01	Spool Assy	21 63	37	JX112-01	O/S Drive Gear	0 72
6	XX044-01	Brake Shoe B	5 56	38	JX083-01	Trn Ratchet	1 03
7	JX106-01	Bearing - Spool Shaft	6 39	39	JX111-01	Washer - Ratchet	0 52
8	JX301-01	Frame Assy	36 93	40	JX012-01	Drive Gear	8 76
9	QW120-01	E-Clip - Worm Shaft	0 15	41	JX059-01	Drag Disc	0 21
10	JX067-01	Bushing - Worm Shaft	0 31	42	JX045-01	Drag "D" Washer	0 98
11	JX347-01	Line Guide Camer Assy	2 27	43	CW052-01	Sleeve - One Way Bearing	3 09
12	JX006-01	Line Guide Pawl	1 80	44	TW058-01	Bearing - Crank Shaft(U)	6 13
13	JX035-01	Washer - Line Guide Pawl	0 21	45	JX038-01	Crank Shaft Washer	0 31
14	JX007-01	Screw - Line Guide Camer	0 52	46	JX066-01	Crank Shaft Guide	3 81
15	NX092-01	E-Clip - Kick Lever Guide Post	0 15	47	JX073-01	O-Ring - Thumb Screw	0 31
16	XX035-01	Washer - Kick Lever Guide	0 98	48	JX074-01	Thumb Screw	1 39
17	JX050-01	Screw - Thumb Rest	0 36	49	JX024-01	Right Side Cover	9 01
18	JX009-01	Thumb Rest	0 62	50	QW123-05	Right Side Cover Screw	0 62
19	JX061-01	Line Guide Camer Guide	1 13	51	JX105-01	Spring - Tension Knob	0 36
20	JX016-01	Worm Shaft Guide	0 82	52	QW032-02	Washer - Spool Tension	0 26
21	JX372-01	Worm Shaft Assy	7 88	53	JX082-01	Washer - Cushion	0 21
22	JX025-01	Pinion Yoke	0 62	54	XX033-01	Spool Tension Knob	2 63
23	JX040-01	Yoke Spring	0 15	55	JX046-01	Spring "D" Washer	0 77
24	JX011-01	Pinion Gear	6 13	56	JX055-01	Star Drag	3 66
25	JX017-01	Bushing - Crank Shaft(L)	0 88	57	NX054-01	Handle Washer	0 15
26	QW120-01	E-Clip - Crank Shaft	0 15	58	JX318-01	Handle Assy	13 34
27	JX002-01	Retainer - Crank Shaft	0 62	59	QW003-01	Handle Nut	0 46
28	JX107-01	Screw - Crank Shaft Retainer	0 15	60	JX034-01	Handle Nut Cap	0 41
29	JX077-01	Kick Lever	0 62	61	QW123-04	Handle Nut Cap Screw	0 21
30	JX097-01	Spring - Kick Lever	0 21	62	UQ063-02	One Way Bearing	7 52
31	JX068-01	Bushing - Release Slider Guide	1 24	63	JX117-01	Bushing - Tension Knob	0 57
32	JX104-01	Spring - Release Slider	0 21	64	JX044-01	Brake Shoe A	0 21

Prices subject to change without notice. Prices do not include postage and handling.
 PLEASE ORDER BY PART NUMBER

